

## IR Codes, ReportMappingTable, and Input.inf

*Please note that the tables in this section may not translate well to the formatting of this page. The original tables are available for download as a PDF [here](#) or at the bottom of this guide.*

IR Codes for "ReportMappingTable" value. Not all Xbox 360 buttons listed, they are the same as the Media Center Remote.

<b>Microsoft Universal Media Remote for Xbox 360</b>					
<b>Button</b>	<b>Value</b>	<b>Button</b>	<b>Value</b>	<b>Button</b>	<b>Value</b>
Power	0x0C	Stop	0x19	Menu	0x24
Start	0x0D	Next trk	0x1A	Red B	0x25
Info	0x0F	Prev trk	0x1B	Yellow Y	0x26
Ch/Pg +	0x12	Up	0x1E	Open / Close	0x28
Ch/Pg -	0x13	Down	0x1F	Display	0x4F
Fast Fwd	0x14	Left	0x20	Title	0x51
Rewind	0x15	Right	0x21	Silver X	0x64
Play	0x16	Select	0x22	Green A	0x66
Pause	0x18	Back	0x23	Blue X	0x68
<b>Media Center Remote</b>					
<b>Button</b>	<b>Value</b>	<b>Button</b>	<b>Value</b>	<b>Button</b>	<b>Value</b>
0 (rc only)	0x00	Fwd	0x14	TV (kb only)	0x46
1 (rc only)	0x01	Rew	0x15	Music (kb only)	0x47
2 (rc only)	0x02	Play	0x16	Recorded TV	0x48
3 (rc only)	0x03	Record	0x17	Pictures (kb)	0x49
4 (rc only)	0x04	Pause	0x18	Videos (kb)	0x4A
5 (rc only)	0x05	Stop	0x19	Radio (kb)	0x50
6 (rc only)	0x06	Skip	0x1A	Videotext (rc)	0x5A
7 (rc only)	0x07	Replay	0x1B	Red (rc)	0x5B
8 (rc only)	0x08	# (rc only)	0x1C	Green (rc)	0x5C
9 (rc only)	0x09	* (rc only)	0x1D	Yellow (rc)	0x5D
Clear (rc only)	0x0A	Up	0x1E	Blue (rc)	0x5E
Enter (rc only)	0x0B	Down	0x1F	Messenger (kb)	0x64
PC Power	0x0C	Left	0x20		

Green Logo	0x0D	Right	0x21		
Mute	0x0E	OK	0x22		
Info	0x0F	Back	0x23		
Vol+	0x10	DVD Menu	0x24		
Vol-	0x11	Live TV	0x25	(rc only) – MS MCE remote	
Ch/Pg +	0x12	Guide	0x26		
Ch/Pg -	0x13			(kb only) - MS MCE keyboard	
<b>HP Remote</b>					
<b>Button</b>	<b>Value</b>	<b>Button</b>	<b>Value</b>	<b>Button</b>	<b>Value</b>
Power	0x0C	More Info	0x0F	Visualization	0x32
Print	0x4E	Aspect	0x27	Slide Show	0x33
Eject	0x34	Pictures	0x49	Videos	0x4A
Music	0x47	Radio	0x50		
Other HP Remote buttons are same as the MCE buttons indicated above.					

The Hexadecimal values above are used within the “ReportMappingTable” value noted on the following page. The “ReportMappingTable” value can be altered by creating a custom INF file or editing the Registry entry. After changing the value must restart Windows or the eHome under USB in Device Manager must be disabled and re-enabled for changes to take affect.

Windows MC Remote settings are installed using the INPUT.INF file.