

VF310 cable reference diagram

This is a general overview illustrating how the internal PCBs interconnect. The VFD should be switched to 'S-GRAPH' by default, which uses the built in IR controller. Please refer to your motherboard manual for the location of the correct ports and header pins.

- 1 - VFD/IR module (VF310)
- 2 - IR selector switch (**S-GRAPH is default**)
- 3 - Main power button PCB (M-PWBT-P1)
- 4 - Standby ATX power cable (M-ATXS-C1)
- 5 - Internal USB cable (M-IUSB-C1)
- 6 - Power on/off cable (M-IPSW-C1)
- 7 - System LED cable (M-SLED-C1)

